

EWI4000s音色表 (工場出荷時)

2006年10月12日現在

プログラム	音色名	プログラム	音色名
01	Singing Song	51	Deep Bass
02	J Judd	52	Detune Pulse
03	Sumo	53	DuckSauce
04	Wood Wind	54	Warm Detune
05	Mimi	55	Dual PWM
06	Pulse Brass	56	Bright Synth
07	Double Reed	57	M EWI
08	Soul Saw	58	Wood Wind 2
09	Mellow	59	DownNDirty
10	Nightcrawler	60	Earthy
11	HowLowCanYouGo	61	Edgy Pulse
12	Fat Bottom	62	Square Wave Wah
13	Funky Wah	63	Reed
14	Bright Wah	64	Feedbacker
15	Recorder	65	Fat PWM
16	Mix Lead	66	Smooth Synth
17	SpiritVoice_5th	67	Wide PWM
18	Tuba	68	Saxy
19	Solid Brass	69	Oxygen
20	Squids+5	70	Common Fanfare
21	Pipe	71	ClareInNet
22	Tonette	72	YawnHummer+5
23	OctaveSteps	73	Mass Ave.
24	SteamPipe	74	Dual Pulse
25	Square Wave50% Width	75	New Wood
26	TrainToHastings	76	Pitchy
27	BuffyCramdon	77	Detune Saw
28	Saw -4	78	DirtyDown4th
29	Square Wave 90% Width	79	DarkBass
30	Fat Saw	80	Warm Detune
31	Pulse Brass	81-100	00-20の音色が重複して納められています。
32	Judd4000	Notes:	上記の図はEWI4000の工場出荷時の状態の音色は位置です。
33	Gross Saw		
34	Dual Pulse		
35	Soprano		
36	Funky Cry Baby		
37	NYStreets-3rd		
38	Square Wave 75% Width		
39	FatterSaw		
40	Saw+5		
41	Clear Saw		
42	Synth Solo		
43	Cantabile Saw		
44	Stonehenge		
45	Crispy		
46	Square Wave 10% Width		
47	Soft Pulse		
48	Silky		
49	Espresso		
50	WoodNGLue		

AKAI professional

Copyright(c) 2006 Pro Audio Japan K.K. All rights reserved.